

2.3. Connect and configure a device

Application Manual

www.pinetek-networks.com



Table of Contents

2.3. Connect and configure a device	5
<i>Connect an IO-Link® device</i>	5
<i>Configure an IO-Link device</i>	5
<i>Device data</i>	6
<i>Enable power</i>	6
<i>Test the device</i>	7

2.3. Connect and configure a device

Connect an IO-Link® device


IO-Link devices are connected with an standard M12 connector to the Pinebox. In our example we will use a distance sensor. Anyhow, the configuration principle is the same for all device types and all available ports on the Pinebox.




If your device does not have a M12 connector, you will need an adaptor or open-connections cable.

Configure an IO-Link device


First, the IODD needs to be loaded. Download the file from your device manufacturer and upload it over the web interface (Step 1: Select file, step 2: upload). The Pinebox accepts zip-Files and plain .iodd files (in xml-Format):



Now you see the device information in the info section:



If the device is applicable to more than one device type, you can select the connected device via the dropdown menu. The selection however does not have a functional impact, it just changes the image of the device:




Device data

The device data is separated in the following sections:


- **Process data:** This is data that is cyclically exchanged, like distance values for a distance sensor
- **Parameters:** This is data that is used to check and configure the device, e.g., with serial number, or threshold values

Enable power

To communicate with the device, you need to apply port power by clicking the “Power ON” button. Please not that this activity will take a short time to be completed.



When power is enabled, the information of the connected device is visible:




Test the device


After enabling power, you can test the device by reading and writing information in the parameter section, e.g. the hardware and firmware revision:



You can also exchange process data (the data might not be complete on the first click):



If the device has process data OUT (data from the Pinebox to the device), the values can be set in the corresponding section. You can also auto-update the process data cyclically with the switch on the top of the page:



Congratulations! You just finished configuring the first device on the Pinebox!