Q: I sporadically receive timeouts from the iol-master-appl

Hardware manual

www.pinetek-networks.com




Table of Contents

Q: I sporadically receive timeouts from the iol-master-appl 5
A: Raise the realtime level of the iol-master-appl 5

Q: I sporadically receive timeouts from the iol-master-appl

The timeouts usually look like this:

```
[16:37:36 WARN ] iolink_dl_handle_error: Reception timeout: 9f
```

followed by a reconnect or connection loss.

A: Raise the realtime level of the iol-master-appl

The issue comes from too low priority for the communication between the stack (`iol-master-appl`) and the `MAX14819`.

To raise the realtime level, you need to set the parameter `-i`, allow `cpuisol` on your device, and run the `iol-master-appl` with `sudo`. The details are described here: Command Line Timing.