

3.2 CMD_LED

Hardware manual

www.pinetek-networks.com




Table of Contents

3.2 CMD_LED	5
-------------------	---

3.2 CMD_LED

The LED command switches the LED on the corresponding port.

Command:

Octet #	Usage
0	Command ID = 0x02
1	Port index 0x00 or 0x01
3	LED Status (see below)

The LED status is 0x01 for the green LED and 0x02 for the red LED. With LED status 0x03, both LEDs are activated.

Return Success:

Octet #	Usage
0	Command ID = 0x02
1	Port index 0x00 or 0x01
3	LED Status