

4 Pinebox configuration

User manual

www.pinetek-networks.com



Table of Contents

4 Pinebox configuration	5
-------------------------------	---

4 Pinebox configuration

This section describes how the the Pinebox and the ports are configured through the integrated web interface.