7 SQLite Database

Hardware manual

www.pinetek-networks.com




Table of Contents

7 SQLite Database 5

7 SQLite Database


The Pinebox is equipped with a pre-installed SQLite database: https://www.sqlite.org

This section describes how the SQLite database is accessed from Node-RED and how the frontend can be accessed over the web interface.

Please note that the storage on the Pinebox is limited. The Pinebox is equipped with an internal eMMC, too many write cycles may eventually damage the memory.

You can install the node node-red-contrib-os via the palette manager to get an overview on the consumed disk memory with the “Drives” node:





It is recommended to wipe old data from the database, if it is no longer needed.