

4 Pinebox configuration

Application Manual

www.pinetek-networks.com



Table of Contents

4 Pinebox configuration	5
--------------------------------------	----------

4 Pinebox configuration

This section describes how the the Pinebox and the ports are configured through the integrated web interface.