3 Connections and web interface

Hardware manual

www.pinetek-networks.com




Table of Contents

3 Connections and web interface 5

3 Connections and web interface

This section describes in detail the physical connection of the Pinebox and the access and functions of the web interface.