4 Pinebox configuration

Hardware manual

www.pinetek-networks.com



Table of Contents

4 Pinebox configuration 5

4 Pinebox configuration

This section describes how the Pinebox and the ports are configured through the integrated web interface.