1.5 Special functions

Hardware manual

www.pinetek-networks.com





Table of Contents

1.5 Special functions 5
Upload configuration 5
Restore Factory Defaults 5

1.5 Special functions

This section covers the handling of dedicated functions like configuration restore.



Upload configuration

The “Upload Configuration” will save the configuration previously downloaded via “Save Configuration” in a folder called staging_conf in the working directory (from where the IOL Connect Manager has been started). Then the application wil exit. When restarted, the IOL Connect Manager looks for the staging_conf content and writes this to the active configuration. The restart process can either be done manually or by putting the IOL Connect Manager in a loop (as shell script).

Restore Factory Defaults

The “Restore Factory Defaults” will delete any user configuration and replace it with factory default settings, except for the IP settings. After this, the application wil exit and needs to be started by new. The restart process can either be done manually or by putting the IOL Connect Manager in a loop (as shell script).